# **Over-winter checks**

Having stored your fishing gear away it's easy to overlook some basic maintenance checks which could bring a nasty shock when we get out on the water again.

- 1. Completely empty your box and bag and make sure there is no water or dirt to hold moisture and mould.
- 2. Hang clothing up in a dry ventilated area and hang boots and waders upside down to avoid cracks and stretched seams.
- 3. Wash and re-proof and dry waterproofs following manufacturers' instructions.

### Rods

- 4. Take rods out of tubes and bags to check they are dry, cork handles can go mouldy if stored damp and clean reel fittings.
- 5. Check rod rings for wear especially the tip ring and replace if there are any grooves.
- 6. Clean the joints and lightly rub bees or candle wax onto any stiff ones.

### Reels

- 7. Remove spools from cassette reels so they don't stick to the O-rings.
- 8. Slacken off the drag screw.
- 9. Rinse in warm water and clear any dirt, dry and add a light smear of grease to the tip and base of the spindle, wipe away any excess.

## Lines

- 10. Wash in warm water with a few drops of detergent, strip off the revolving spool (not the side to avoid twisting) stretch out (between door handles or chairs not on a carpet) and wipe with damp cloth. Check braided loops are not frayed and look for any cracks or other damage and treat floating lines with a line dressing eg Lineslick. Some use this on sinkers too. Minor damage can be repaired with superglue and whipping.
- 11. Check your hang markers are visible and touch them up with marker pens or whipping.
- 12. Once dry, wind back onto the cassette but loosely as a firm wind will create memory while in storage.

#### **Flies**

- 13. Discard any damaged or rusty flies and dry out foam boxes.
- 14. With plenty of time on our hands why not re-box them by pattern or barbed and barbless or competition size boxes.
- 15. A coat of varnish can rejuvenate your buzzers and heads of other flies.